

HEIDENHAIN



Evaluation Electronics For Metrology Applications

03/2021

Contents

For many metrology applications, ranging from simple measuring stations to complex inspection systems with multiple measuring points, HEIDENHAIN supports you with compatible evaluation electronics.

Their functionality is always oriented toward the specific application. Whether for an SPC inspection station, profile projector, or measuring microscope, the HEIDENHAIN **evaluation electronics for metrology applications** are the right choice for your measurement tasks.

Digital readouts from HEIDENHAIN for manually operated machine tools

optimally support the operator with practical cycles for milling, drilling, and turning. You can find these digital readouts on the Internet at www.heidenhain.de or in the *Digital Readouts and Linear Encoders for Manually Operated Machine Tools* brochure.



Evaluation electronics for measurement and inspection tasks

| Overview | | | | |
|----------------------------------|---------------------------------------|---|----|--|
| | Selection guide f | for measurement and inspection tasks | 4 | |
| Specifications | | | | |
| Measurement and inspection tasks | ND 280: evaluati | tion unit for simple measuring and positioning tasks | 6 | |
| | ND 287: evaluati | tion unit for measuring and inspection stations | 8 | |
| | GAGE-CHEK 20 | 000: evaluation unit for demanding measured-value acquisition | 10 | |
| | EIB 700: signal c | converter for computer-aided measured-value acquisition | 14 | |
| | IK 220: signal co | onverter for computer-aided measured-value acquisition | 16 | |
| Mounting | | | | |
| Dimensions and installation | ND 200 | | | |
| | EIB 700 | EIB 700 | | |
| | GAGE-CHEK 200 | 00 | 20 | |
| | Accessory: adap | Accessory: adapter connectors | | |
| | Accessory: external operating element | | | |
| Electrical connection | | | | |
| | Interfaces | Overview | 23 | |
| | | Optional assemblies for the ND 287 | 24 | |
| | | Switching inputs/outputs on the ND 287 | 25 | |
| | | EIB 700 and IK 220 evaluation electronics | 27 | |
| | | Encoder inputs | 28 | |
| | | EIB application software for the EIB 700 | 31 | |



Comprehensive descriptions of all available interfaces as well as general electrical information are included in the *Interfaces of HEIDENHAIN Encoders* brochure (ID 1078628-xx).

For the required cables, please refer to the *Cables and Connectors* brochure (ID 1206103-xx).

You can download the operating instructions in the desired language free of charge from the HEIDENHAIN homepage.

This brochure supersedes all previous editions, which thereby become invalid. The basis for ordering from HEIDENHAIN is always the brochure edition valid when the order is placed.

Standards (ISO, EN, etc.) apply only where explicitly stated in the brochure.

Selection guide Measurement and inspection tasks

| | Screen | Axes | Functions | Options/Additional functions | Model | Page |
|--|-------------|-------------------------|--|---|--------------------|------|
| | | Length Angle | | | | |
| ND 200 Evaluation unit for | Monochrome | 1 (adjustable) | - | - | ND 280 | 6 |
| Measurement equipment Adjustment and inspection equipment SPC inspection stations Simple infeed and positioning tasks | Color | Up to 2 (adjustable) | Metrological and statistical functions (sorting and tolerance checking, measurement series, SPC) | Second encoder for sum/difference display, temperature compensation | ND 287 | 8 |
| GAGE-CHEK 2000 Evaluation unit for | Color | Up to 3 (adjustable) | Acquisition of precise measured values, and spot-on positioning in metrology applications | - | GC 2013 | 10 |
| Positioning equipment | touchscreen | (adjustable) | 100 presets | | GC 2023 | 3 |
| Measuring fixtures Adjustment and inspection equipment | | | Dial gage: comparison of the displayed value with nominal value, warning threshold, and tolerance threshold Measurement series with minimum and maximum value recording Difference of minimum and maximum values (range) Measurement of master parts (mastering) Data transfer either manually, continuously, or triggered by touch probe or switching function Diameter/radius display Relative measurement Probing functions: edge, centerline, and circle User administration Configurability of each axis for length or angle display Coupled axis for sum measurement or differential measurement | | GC 2093 | |
| EIB 700 Signal converter for computer-aided measured-value acquisition on • Measuring machines • Inspection stations • Multi-gauging fixtures • Mobile data acquisition | PC screen | 4 (adjustable) | Precise position measurement; updating rate of up to 50 kHz Programmable measured-value inputs Internal and external measured-value triggers Measured-value memory for typically 250 000 measured values per channel Standard Ethernet interface connection to higher-level computer systems | Mounting bracket for 19-inch systems | EIB 741 EIB 742 | 14 |
| IK 220 Signal converter as a PCI slot card for computer-aided measured-value acquisition on measuring and inspection stations | PC screen | 2 (adjustable) | Programmable measured-value inputs Internal and external measured-value triggers Measured-value memory for 8192 measured values per channel | Assemblies for encoder outputs and external inputs/outputs | IK 220 | 16 |



ND 287



GAGE-CHEK 2000





ND 280 Evaluation unit for simple measuring and positioning tasks



is is **Functions**

The ND 280 evaluation unit for one axis is suitable for measuring and inspection stations, as well as simple positioning tasks. The universal encoder input permits the connection of all incremental encoders with 11 μ APP and 1 VPP signals, and absolute encoders with the EnDat 2.2 interface from HEIDENHAIN.

Design

The ND 200 series features a sturdy aluminum die-cast housing. Its splash-proof, full-travel keyboard is built to handle shopfloor conditions. For displaying the measured values, a graphics-capable screen shows the status display and soft keys. The **ND 280** digital readout provides all of the key functions for simple measuring and positioning tasks. Expanded functionality is offered by the ND 287 evaluation unit (e.g., for metrological acquisition and statistical analysis of measured values). Thanks to its switching inputs and outputs, the ND 287 can also be deployed in simple automated environments (see p. 8).

Data interfaces

The ND 280 is equipped with serial interfaces for the transmission of measured values to a PC or printer, for the input/ output of parameter lists and compensation value lists, and for diagnostics: USB RS-232-C/V.24



| | ND 280 | | |
|---|---|--|--|
| Axes | One | | |
| Encoder inputs | \sim 1 V _{PR} \sim 11 μ A _{PR} or EnDat ¹⁾ : 15-pin | | |
| Input frequency | \bigcirc 1 V _{PP} : ≤ 500 kHz; \bigcirc 11 µA _{PP} : ≤ 100 | | |
| Subdivision factor | 4096-fold | | |
| Display step ²⁾ | Adjustable, max. 9 digits <i>Linear axis:</i> 0.5 μm to 0.002 μm <i>Angular axis:</i> 0.5° to 0.00001° or 00°00′0 | | |
| Display | Monochrome TFT screen | | |
| | Position values, dialog boxes, input fields, | | |
| Status display | Operating mode, REF, preset, scaling facto | | |
| Functions | REF reference-mark evaluation for distant Two presets Distance-to-go mode Integrated help and diagnostics External operation via serial interface | | |
| Axis-error compensation | <i>Linear axis:</i> linear, and segmented linear <i>Angular axis:</i> segmented linear with 180 | | |
| Data interface | • RS-232-C/V.24 • USB (Type B) | | |
| Power connection | AC 100 V to 240 V (-15 % to +10 %), 48 H | | |
| Operating temperature | 0 °C to 50 °C (storage temperature: -40 °C | | |
| Protection EN 60529 | IP40; front panel: IP54 | | |
| Mass | Approx. 2.5 kg | | |
| ¹⁾ Purely serial with no evaluation of incremental signals | | | |

¹⁾ Purely serial, with no evaluation of incremental signals

²⁾ Depends on the signal period of the connected encoder (Display step \approx Signal period/4096)

in D-sub (female, automatic interface detection)

00 kHz

00.1"

graphing functions, and soft keys

tor, compensation, stopwatch, unit of measure, soft-key level

ance-coded or single reference marks

ear via 200 compensation points 0 compensation points (every 2°)

Hz to 62 Hz; 30 W

°C to 85 °C)

ND 287 Evaluation unit for measuring and inspection stations

Thanks to its extensive functionality, the ND 287 evaluation unit for one axis is well suited for measuring and inspection stations, and can also be used for simple positioning tasks. The universal encoder input permits the connection of all incremental encoders with 11 μ App and 1 Vpp signals, and absolute encoders with the EnDat 2.2 interface from HEIDENHAIN.

Design

The ND 287 features a sturdy aluminum die-cast housing. For displaying the measured values, a graphics-capable screen shows the status display and soft keys. Its splash-proof, full-travel keyboard is designed to handle the shop floor.

Functions

The **ND 287** provides numerous functions for the metrological acquisition of individual values, including functions such as sorting and tolerance check mode, minimum and maximum value recording, and measurement series storage. Based on these data, mean values and standard deviations can be calculated and displayed in histograms or control charts. Thanks to its modular design, the ND 287 permits the connection of a second encoder for sum/difference measurement, or the connection of an analog sensor (e.g., for temperature compensation).

Data interfaces

The ND 287 is equipped with serial interfaces for the transmission of measured values to a PC or printer, for the input/ output of parameter lists and compensation value lists, and for diagnostics:

- USB
- RS-232-C/V.24
- Ethernet 100BaseT (option) The transmission of measured values can

be initiated on the ND keyboard or via an external command. With RS-232-C/V.24, this is done using the software command CTRL+B or a configurable internal clock.

Sorting and tolerance checking

With the sorting and tolerance checking function of the ND 287, workpieces can be inspected for dimensional accuracy and sorted into classes. The result is shown through symbols in the color status display, with a corresponding signal applied at the switching outputs.

Display freeze

For readability, even during rapidly changing measured values, the display can be frozen with an external signal. The internal counter keeps on running.

Mathematical consideration of a second encoder

A second encoder or a sensor can be connected to the ND 287 through an optional **encoder module** or **analog module** input assembly. The data from the two encoders can be taken into account mathematically via operands. The result and the two measured values are saved. This opens up further areas of application, such as sum/ difference display of two encoders or temperature compensation by means of a temperature sensor.

Recording and evaluating measurement series


The ND 287 provides a measured-value memory for the storage of measurement series. Alternatively, during the measurement series, the minimum, maximum, or difference can be displayed. The displayed value can also be checked for tolerance conformity with the sorting function. The saved measured values are evaluated and displayed in the following ways:

- Statistical view (mean value x, standard deviation s, and range r)
- Diagram (graph of the measured values with minimum, maximum, and mean
- values, as well as tolerance limits)
- Measured value overview as a table

Statistical Process Control (SPC)

For SPC, the ND 287 saves up to 1000 measured values in its nonvolatile FIFO memory. Evaluation is performed with the following functions:

- Statistical view of the measured values in the FIFO memory
- Measured value overview as a table
- Diagram of the last 30 measured values
- Histogram in ten classes with probability density function and process capability indexes Cp and Cpk.
- Control charts for mean value x, standard deviation s, and range r




9.061.7

C ENT

0.

Sorting and tolerance checking



Sum measurement

Measured value acquisition

STOGRAM

CONTROL

CHARTX

1/5 51 💼

0.4

HELP

Cp =

Cpk =

| | ND 287 |
|---|--|
| Axes | One; option: second input through encode |
| Encoder inputs Input frequency | \bigcirc 1 V _{PB} \bigcirc 11 µA _{PB} or EnDat ¹⁾ (autom \bigcirc 1 V _{PP} : ≤ 500 kHz; \bigcirc 11 µA _{PP} : ≤ 100 |
| Subdivision factor | 4096-fold |
| Display step ²⁾ | Adjustable, max. 9 digits <i>Linear axis:</i> 0.5 μm to 0.002 μm; <i>angular a</i> . |
| Analog input | Option: ±10 V via analog module; resolutio |
| Display | Screen for position values, dialog boxes, in |
| Functions | REF reference-mark evaluation for distar Two presets and distance-to-go mode External operation via serial interface Sorting and tolerance checking Measurement series with minimum and Storage of measured values (up to 10 000000000000000000000000000000000 |
| Axis-error compensation | <i>Linear axis:</i> linear, and segmented linea <i>Angular axis:</i> segmented linear with 180 |
| Data interface | RS-232-C/V.24; USB (Type B); option: Ether |
| Switching outputs for automation tasks | Zero crossover; trigger points 1 and 2 Sorting signals "<" and ">" Errors |
| Switching inputs for automation tasks | Zero reset, set displayed value Move to reference point and ignore reference point and ignore reference value output or display freeze Start measurement series Minimum, maximum, and difference dis Gating of the two encoder inputs Sum or difference display Display of measured value 1 or measure |
| Accessories | Mounting adapter, encoder module, analog |
| Power connection | AC 100 V to 240 V (-15 % to +10 %), 48 Hz |
| Operating temperature | 0 °C to 50 °C (storage temperature: –40 °C |
| Protection EN 60529 | IP40; front panel: IP54 |
| Mass | Approx. 2.5 kg |
| 1) | |

ND 287

¹⁾ Purely serial, with no evaluation of incremental signals

²⁾ Depends on the signal period of the connected encoder (Display step \approx Signal period/4096)

er module

matic interface detection) 10 kHz

axis: 0.5° to 0.00001° (00° 00' 00.1")

on: 5 mV

nput fields, graphing functions, and soft keys

nce-coded or single reference marks

d maximum value recording)00) (SPC) gram ncoder module) odule)

ar via 200 compensation points compensation points (every 2°)

ernet 100BaseT, via Ethernet module

erence signals

splay

ed value 2

g module, Ethernet module

z to 62 Hz; 30 W

C to 85 °C)

GAGE-CHEK 2000 Evaluation unit for demanding measured-value acquisition

The GAGE-CHEK 2000 evaluation unit is particularly well suited for positioning tasks on positioning, measuring, adjustment, and inspection equipment, as well as for the retrofitting of measuring machines in order to collect and transmit data to a PC.

Design

Thanks to its rugged industrial design, the GAGE-CHEK 2000 is superbly suited for applications in measuring rooms and harsh production environments. Its slim aluminum housing, featuring an integrated power adapter and fanless passive cooling system, is exceptionally sturdy and resilient. The unit's straightforward touchscreen, made of specially hardened glass, supports multi-touch gesture control and permits operation with gloves.

Functions

The logical arrangement of menus and function elements provides intuitive user guidance, which supports you while using the different functions. Along with the typical functionality of an evaluation unit, such as zero resetting and preset setting. the GAGE-CHEK 2000 also offers the following practical features:

- Dial gage for a graph of the measured value
- Measurement series with minimum and maximum value recording
- Measurement of master parts (mastering) • Coupled axis for sum measurement or differential measurement
- Probing functions
- Manual, continuous, touch-probetriggered, or switching-function triggered measured value output


Over the data interface, you can transfer the captured measured values to a PC.

Configurable axis names

The axis names shown in the display can be changed to meet the requirements of the given application. By means of an alias assignment, you can easily change the names of the X, Y, and Z axes. The axis names may contain any combination of up to two letters and/or numbers.


Intuitive display

All of the information you need is displayed in a clean and easy-to-read format on the unit's high-resolution, 7-inch screen. Only those functions that are actually available within a given context and situation are shown. The self-explanatory operating elements provide intuitive user guidance.



Diameter/radius display

The "D/R" (diameter/radius) function can be used for radial measurements on rotationally symmetrical parts; for example, in order to switch between the displayed radius and the equivalent diameter. The axes to be given this switching capability can be configured within the function, which can be used on linear axes or on angular axes displayed as linear axes.



Management of parts

The GAGE-CHEK 2000 allows you to

measurement and to store them in a

configure functions for various objects of

structured manner in the function bar. The

required measurement functions can thus

11.963

15.181

0.304

Sum/differential measurement

With the coupled axis, two encoder inputs can be shown linked in the position display. For this purpose, the two encoder inputs are offset against each other as a sum or difference. The result is shown as coupled axis in the position display.




| | GAGE-CHEK 2013 | GAGE-CHEK 2023 | GAGE-CHEK 2093 | | |
|-----------------------|---|--|---|--|--|
| | | | | | |
| Axes | Up to three axes | | | | |
| Encoder interface | ∼ 1 V _{PB} ∼ 11 μA _{PB} EnDat 2.2 | | 1 connection: Π ITTL 2 connections: ~ 1 V _{PP} ~ 11 μA _{PP} EnDat 2.2 | | |
| Input frequency | 1 V_{PP}: ≤ 400 kHz 11 μA_{PP}: ≤ 150 kHz | ≤ 5 MHz | $\begin{array}{c} & \swarrow 1 \ V_{PP}: \leq 400 \ \text{kHz} \\ & \swarrow 11 \ \mu A_{PP}: \leq 150 \ \text{kHz} \\ & \Box \ \Box$ | | |
| Subdivision factor | 4096-fold (only with 1 V _{PP}) | | | | |
| Display step | Configurable, up to eight digits Linear axes X, Y, and Z: down to 0 | Configurable, up to eight digits Linear axes X, Y, and Z: down to 0.000 01 mm; rotary axis Q: down to 0.000 01° (00° 00′ 00.1″) | | | |
| Display | 7-inch screen (15:9) for multitouch operation; resolution: WVGA 800 x 480 pixels for dialog boxes, input fields, position values, and graphing functions | | | | |
| Functions | Acquisition of precise measured values, and spot-on positioning in metrology applications 100 presets Dial gage for a graph of the measured value Measurement series with minimum and maximum value recording Difference of minimum and maximum values (range) Measurement of master parts (mastering) Data transfer either manually, continuously, or triggered by touch probe or switching function Diameter/radius display Relative measurement Probing functions (edge, centerline, and circle) User administration Configurability of each axis for length or angle display Coupled axis for sum measurement or differential measurement | | | | |
| Error compensation | Linear (LEC) and segmented linear (SLEC) using up to 200 compensation points Squareness calibration; matrix compensation (NLEC) using up to 99 x 99 points | | | | |
| Data interface | 1x Ethernet 100 Mbit/1 Gbit (RJ4 | 1x Ethernet 100 Mbit/1 Gbit (RJ45); 1x Hi-Speed USB 2.0 (Type A) | | | |
| Other connections | Foot switch for two functions | Foot switch for two functions | | | |
| Accessories | Multi-Pos, Duo-Pos, and Single-Po | Multi-Pos, Duo-Pos, and Single-Pos stands, Multi-Pos holder, power cable, adapter connector, foot switch | | | |
| Power connection | AC 100 V to 240 V (±10 %); 50 Hz to 60 Hz (±5 %); \leq 38 W | | | | |
| Operating temperature | 0 °C to +45 °C (storage temperate | ure: -20 °C to +70 °C) | | | |
| Protection EN 60529 | IP65; back panel: IP40 | | | | |
| Mounting | Multi-Pos, Duo-Pos, or Single-Pos | Multi-Pos, Duo-Pos, or Single-Pos stand; Multi-Pos holder; 50 mm $	imes$ 50 mm mounting hole pattern | | | |
| Mass | Device with Multi-Pos stand: approx. 2.0 kg; device with Duo-Pos stand: approx. 1.5 kg; device with Multi-Pos holder: approx. 1.7 kg; device alone: approx. 1.3 kg | | | | |

Functions

Configurable function elements

The functionality of the GAGE-CHEK 2000 can be adapted to the given requirements through individually configurable function elements in the Inspector view. Along with function elements for the output of measured values, functions such as a preset table and the storage of minimum and maximum values are available as well.




Y

5.968

Call

Recording minimum and maximum values (MinMax)

The GAGE-CHEK 2000 is equipped with a function for recording minimum and maximum values. This function can be configured for the axes as desired. The highest and lowest measured values of a measurement series, including their difference, are recorded and can be output over the data interface. This function is particularly advantageous for radial run-out inspection.



Dial gage

The dial gage function lets you make a direct comparison between the acquired measured values and the nominal value, warning limits, and tolerance limits. The measured values are shown as a graph in the form of a dial gage. For evaluation, the GAGE-CHEK 2000 supports you with a color depiction of a dial gage.

X

Ζ

15.082

2.756



The probing functions support you in determining positions and presets. For these purposes, the GAGE-CHEK 2000 provides edge, centerline, and circle-center probing functions.

| 15:50 | The ce | nter lir | the cente ne was d et to app |
|-------|--------|----------|------------------------------------|
| | Selec | ted pr | eset |
| | 0 | 6 | P159 |
| | 1 | 6 | P123 |
| ¢ | Set po | osition | values |

Mastering

With the mastering function, you can reduce influences on the measurement results of a measurement series by using master parts. For this purpose, the master part is measured regularly with the known dimensions. The documented measured values of the master part are taken over either individually or entirely in the position display of the corresponding axes. Regular mastering helps you to improve the accuracy of your measurement series. In addition, you can reuse the measuring setup quickly and easily for new measured objects.




....

Configurable data formats for measured-value output

Along with providing a default format, the GAGE-CHEK 2000 also gives you the option of storing your own data formats for data transfer. Thanks to the configurability of its data formats, the GAGE-CHEK 2000 is particularly effective as a data logger on retrofitted, manually operated measuring machines. Within such applications, the GAGE-CHEK 2000 captures the measured values and relays them to a higher-level PC for processing.

| △ 0 15:54 | Settir | igs |
|---------------------|------------|-----|
| \bigtriangleup | General | { |
| | Sensors | (|
| | Interfaces | ę |
| С Ф | User | ٩ |
| ŝ | Axes | * |
| \bigcirc | Service | c |





| | Interfa | ces |
|----------|--|-------------|
| <u>ې</u> | < Data tra | nsfer |
| Ð | RS-232 | X32 👻 |
| te e | Data format for data transfer | Standard 👻 |
| 9 | Data format for touch-probe- triggered data transfer | MyFormat1 🔹 |
| s. | Data format for continuous data transfer | Standard |
| 2 | Data format for switching- function-triggered data transfer | Standard |

13

EIB 700 Signal converter for computer-aided measured-value acquisition

For use as evaluation units, the EIB 700 signal converters feature connections for four encoders. These units are particularly well suited for the following applications:

- Precise position measurement, especially for inspection stations and multi-gauging fixtures
- Portable, on-site data acquisition (e.g., for machine calibration)
- Integration into customized applications (e.g., high-precision measuring machines)

The EIB 700 series is ideal for applications requiring high-resolution encoder signals and rapid measured-value acquisition. Its Ethernet transmission also enables the use of switches or hubs for connecting more than one EIB. Wireless LAN transmission, for example, can be used as well.

Design

The EIB 700 features a bench-top housing. With a mounting bracket accessory, it can also be easily installed into a 19-inch housing. The device is suitable for the following supply voltages: EIB 741: AC 100 V to 240 V EIB 742: DC 24 V

Functions

For **measured-value generation**, the EIB 700 subdivides the signal periods of the incremental signals up to 4096-fold. Automatic adjustment of the sinusoidal incremental signals reduces the error within one signal period.

And thanks to its **measured-value**

memory, the EIB 700 series can typically save 250 000 measured values per axis. Based on the axis, these measured values can be saved by means of either an internal or external trigger.

The **interval counter** permits positiondependent triggering in conjunction with an incremental encoder on Axis 1. For this purpose, the signals of Axis 1 are interpolated and forwarded to a position counter. Triggering pulses are generated either at a certain position or equidistantly at configurable intervals. They are continuously generated once a configurable starting position is crossed in either counting direction. The trigger pulses can be used to trigger further internal axes of the EIB or can also be output over a trigger output.

| Data interface | |
|--------------------------|---------------------------|
| A standard Ethernet inte | erface using ⁻ |

A standard Ethernet interface using TCP/IP or UDP communication is available for **data output**, permitting direct connection to a PC, laptop, or industrial PC. The type of measured-value transmission can be selected through the operating mode (single values, as a block, or upon software request).

For processing the measured values on

a PC, software drivers for Windows, Linux, and LabVIEW are included in delivery, as are example programs and the EIB application software. The software driver makes it easy to program customized applications, and the example programs demonstrate the potential of the EIB 700 series. The EIB application software aids with setting up and demonstrating the capabilities of the EIB 700 series. This software is provided as source code and can serve as a platform for the development of one's own applications.

| Operating modes | Soft Real-Time | Recording | Streaming | Polling |
|----------------------------|---|---|--|--|
| Properties | Immediate transmission of the measured value upon occurrence of the triggering event | Storage of measured values in the EIB's internal measured-value memory | Buffering and block transmission of measured values | Software request originating from the customer's application |
| Selectable trigger sources | All internal and external sources | | | Via software command |
| Trigger rate | \leq 10 kHz (access time to position values < 100 µs) | ≤ 50 kHz | ≤ 50 kHz Up to 1 200 000 bytes/s | Depends on the application |
| Typical applications | Closed Loop control | Very high recording rate Offline data analysis | High recording rate in combination with high recording depth | Semi-static measured value recording |

| | EIB 741 EIB 742 |
|--------------------------------------|--|
| Encoder inputs | 15-pin D-sub connections (female, X11 to |
| Interface (switchable) | ^ 1 V _{PB} |
| Supply voltage for encoders | DC 5.12 V ±0.15 V; max. 450 mA per char Overcurrent protection (automatic switch- |
| Input frequency | ≤ 500 kHz |
| Subdivision factor | 4096-fold |
| Signal adjustment | Automatic adjustment of offset, phase, ar |
| Cable length ¹⁾ | ≤ 150 m |
| Data register for measured values | 48 bits (of which only 44 bits are used) |
| Interval counter | Derived from Axis 1 (only 1 V _{PP}) ⁴⁾ , Configurable interpolation factor from 1-fo Can be used as a trigger source or additio |
| Measured-value memory | Typically 250 000 position values per chan |
| Measured-value trigger ²⁾ | Storage of the measured values of the for External: Signal via trigger inputSoftware command (over EfInternal:Timer and interval counterReference pulse of the resp |
| Trigger input ³⁾ | 9-pin D-sub connection (male); differential |
| Trigger output ³⁾ | 9-pin D-sub connection (female); four diffe |
| Access to measured values | Depends on the selected operating mode |
| Software | Software drivers for Windows, Linux, ar Example programs EIB application software |
| Data interface ⁵⁾ | Ethernet as per IEEE 802.3 (10/100/1000 |
| Network address | Automatic assignment through Dynamic I |
| Dimensions | Approx. 213 mm x 152 mm x 42 mm |
| Operating temperature | 0 °C to 45 °C (storage temperature: 0 °C t |
| Supply voltage | EIB 741: AC 100 V to 240 V (±10 %), 50 Hz EIB 742: DC 24 V (–15 %/+20 %), max. 2 |

¹⁾ The supply voltage range of the encoder must be maintained; specified cable length applies when HEIDENHAIN cables are used.

²⁾ Various trigger sources can be assigned to the individual axes.

³⁾ Can also be used as logical input or output

⁴⁾ Maximum input frequency during referencing: 70 kHz

⁵⁾ The quality of the data cable between the EIB and PC must be adapted to the transmission rate and cable length.

| o X14), for four encoders | | | | | |
|--|-------------------------|-------------------|--|--|--|
| | EnDat 2.1 | EnDat 2.2 | | | |
| annel n-off, resettable) at 550 m | nA | | | | |
| | - | - | | | |
| | - | - | | | |
| and amplitude | - | - | | | |
| | ≤ 150 m | ≤ 100 m | | | |
| | | | | | |
| fold to 100-fold onal counting axis | - | - | | | |
| nnel | | | | | |
| our axes through an exte | rnal or internal trigge | r (selectable). | | | |
| Ethernet) | | | | | |
| pective axis (from Axis 1 | and other axes) | | | | |
| al inputs as per RS-485 (t | erminating resistors | can be activated) | | | |
| ferential outputs as per R | S-485 | | | | |
| le (see separate table) | | | | | |
| and LabVIEW | | | | | |
| | | | | | |
|) Mbit/s) | | | | | |
| Host Configuration Protocol (DHCP), or manual assignment | | | | | |
| | | | | | |
| to +70 °C) | | | | | |
| Hz to 60 Hz (±2 %); max. power consumption: 30 W 2 A | | | | | |
| | | | | | |

IK 220 Signal converter for computer-aided measured-value acquisition



The IK 220 signal converter is an evaluation unit for two axes. As a PC counter card, the IK 220 can be inserted directly into a free PCI slot on the computer.

Design

Connectable to the IK 220 are two HEIDENHAIN encoders with sinusoidal current signals (\sim 11 µA_{PP}), sinusoidal voltage signals (\sim 1 V_{PP}), or an EnDat 2.1 or SSI interface. External latch inputs/ outputs and the output of encoder signals (\sim 11 µA_{PP}) can be implemented by means of additional slot covers (accessory). The IK 220 subdivides the signal periods of the sinusoidal encoder signals up to 4096-fold. The signals are called and stored through either external latch inputs or software.

Functions


The IK 220 features an integrated **measured value memory.** A total of up to 8192 measured values can be stored in the buffer memory and can be output as a single block.

Further processing of the measured values in the PC is performed by operatorcreated programs. To demonstrate the possibilities of the PC counter card,

example programs and a software driver

are included in delivery.

Basic circuit diagram



| | IK 220 | | | | |
|---|--|------------------------|--|--|--|
| Encoder inputs | 15-pin D-sub connections | (male, X1 and X2 | | | |
| Input signals (switchable) | ∼ 1 V _{PP} | ∕~ 11 μA _{PP} | | | |
| Input frequency | ≤ 500 kHz ≤ 33 kHz | | | | |
| Cable length ¹⁾ | ≤ 60 m | 1 | | | |
| Adjustment of encoder signals | Adjustment of offset, pha | se, and amplitud | | | |
| Signal subdivision | 4096-fold | | | | |
| Data register for measured values | 48 bits; of which only 44 b | bits are used for t | | | |
| Internal memory | For 8192 position values | | | | |
| Measured-value trigger | Through the following (selectable): External latch signals (over separate IK a Software command Timers Traversing of reference marks | | | | |
| Access time to measured values | Without adjustment, w ≤ 100 μs With adjustment, without ≤ 110 μs With adjustment, with with adjustment, with 0 ≤ 160 μs | out compensation | | | |
| Interface | PCI bus (plug and play) Lo | cal Bus Specifica | | | |
| Software driver and demonstration program | For Windows 7 (32-bit and In VISUAL C++, VISUAL E Via download: Windows 1 | BASIC, and BORL | | | |
| Outputs for encoder signals | 11 μA_{PP} Via PCB connector on the Fitting cable assembly with | | | | |
| Power consumption | Approx. 4 W, without encoders | | | | |
| Dimensions | 190 mm x 100 mm | | | | |
| Operating temperature | 0 °C to 55 °C (storage ten | nperature: –30 °C | | | |

¹⁾With HEIDENHAIN cable; longer cable lengths upon request

| 2), for two | encoders | |
|--------------|-----------|-----|
| | EnDat 2.1 | SSI |
| | - | |
| | ≤ 10 m | |
| le by the so | oftware | |
| | | |

the measured value

assembly for external inputs/outputs)

| ation run: | Depends on the encoder |
|--------------|------------------------|
| on run: | |
| un: | |
| | |
| ation Rev. 2 | 2.1 |

LAND DELPHI included in delivery

ale) optionally available

°C to 70 °C)

Mounting Mounting the ND 200

ND 200 series

The ND 200 series digital readouts were designed as benchtop units and can be easily stacked. Recesses on the top prevent the stacked units from shifting out of place.

Through threaded holes at the bottom, the ND 28x can be fastened to a base plate with M4 screws.

Two side-by-side ND 28x readouts fit inside a 19-inch housing. For mounting inside a 19-inch housing, a mounting adapter is available as an accessory.

Accessories

Mounting adapter for 19-inch housing ID 654020-01





Mounting the EIB 700


The EIB 700 series was designed as a benchtop unit. It must be installed in a well-ventilated area and at a specified operating orientation.


Through threaded holes at the bottom, the EIB 700 can be fastened to a base plate with M3 screws. Two side-by-side EIB 700 units fit next to each other in a 19-inch housing, thus occupying one height unit. A mounting bracket is available as an accessory.

Accessories **Mounting bracket** For installation of two EIB 74x units in a 19-inch housing. ID 671144-01

















Mounting the GAGE-CHEK 2000

With the Multi-Pos or Duo-Pos stand, the GAGE-CHEK 2000 evaluation units can be set up at different angles of tilt. Mounting to the machine can be accomplished with the Multi-Pos holder or with other fastening systems featuring a 50 mm x 50 mm hole pattern.


Multi-Pos stand


For setup on and fastening to a horizontal surface (90° continuous tilt range).


ID 1089230-07



with Multi-Pos stand







 $1 = Recommended tightening torque: M_d = 6.8 Nm$

mm Tolerancing ISO 8015 ISO 2768 - m H ≤ 6 mm: ±0.2 mm

Duo-Pos stand

For setup on and fastening to a horizontal surface (20° or 45° tilt).

ID 1089230-06

Single-Pos stand Included in delivery. For setup on and fastening to a surface (20° tilt).

ID 1089230-05

Multi-Pos holder For fastening to an arm (90° continuous tilt range).

ID 1089230-08

Mounting arm, straight For fastening to a machine.

ID 1089207-01













21

Accessory: adapter connectors

Adapter connectors for the GAGE-CHEK 2000

For pin-layout conversion from HEIDENHAIN TTL to RSFTTL and Renishaw TTL. ID 1089210-01

For pin-layout conversion from HEIDENHAIN 11 μA_{PP} to HEIDENHAIN 11 µA_{PP}. ID 1089213-01

For pin-layout conversion from HEIDENHAIN 1 VPP to HEIDENHAIN 1 VPP. ID 1089214-01

For pin-layout conversion from HEIDENHAIN 1 VPP to Mitutoyo 2 VPP. ID 1089216-01

Adapter cable for the GAGE-CHEK 2000

For pin-layout conversion from the HEIDENHAIN touch-probe interface to the Renishaw touch-probe interface. ID 1095709-xx

Accessory: external operating element

Although the evaluation units are easy and intuitive to operate, external control capability may be useful in certain scenarios. The foot switch is available for externally controlled operation:

Foot switch (accessory) Cable length: 2.4 m

For GAGE-CHEK 2000, with a 15-pin D-sub connector and two keys. ID 681041-04




11 µApp, 1 Vpp, 2 Vpp

adapter connector

Adapter connector

for TTL



The evaluation units are equipped with interfaces for encoders, communication, and external components.

| | ND 280 | ND 287 | GAGE-CHEK 2000 |
|--|--------|--------|-----------------|
| Encoders | | | |
| 1 V _{PP} /11 μA _{PP} | •/• | ●/● | • |
| TTL | - | - | • |
| EnDat 2.2. ¹⁾ | • | • | • |
| Touch probe | - | - | • ²⁾ |
| Sensor $\pm 10 V$ | - | Option | - |
| Data | | | 1 |
| USB | Туре В | Туре В | Туре А |
| RS-232-C/V.24 | • | • | • ³⁾ |
| Ethernet | - | Option | • |
| Foot switch | - | - | • |
| Switching outputs | - | 6TTL | 1 TTL |
| Switching inputs | - | 12 TTL | 4TTL |

 \bullet = Included

– = Not included

¹⁾ Purely serial, with no evaluation of incremental signals

²⁾ HEIDENHAIN or Renishaw touch probe

³⁾ Possible with RS-232 adapter connection via USB port



Optional assemblies for the ND 287

Various input and output assemblies are available for the evaluation unit.

Second encoder input (option)

The ND 287 evaluation unit can be equipped with an optional second encoder input.

Encoder module

Input assembly for second encoder with a $1\,V_{PB}$ 11 μA_{PB} or EnDat 2.2 interface. ID 654017-01

Analog input (option)

Through an optional input assembly, the ND 287 evaluation unit can be equipped with an additional analog input for connecting a sensor. The input voltage range is interpolated 4096-fold; for a sensor with ±10 V, the resolution is therefore 5 mV. The analog module provides DC 5 V, DC 12 V, and DC 24 V as supply voltage for the sensor.

The DC 5 V (B) and DC 12/24 V (A) supply voltages are galvanically isolated and must not be used at the same time. A 9-pin D-sub connector is required as a mating connector.

Analog module

Input assembly for the ± 10 V analog sensor. ID 654018-01

Ethernet (option)

The ND 287 evaluation unit can be provided with an optional Ethernet module.

Ethernet module

ID 654019-01

This module features an Ethernet 100BaseT interface with an RJ45 connector (8-pin, female), allowing the ND 287 to be connected directly to an internal network or, with a crossover cable, to a PC.

| 0 | 0 | 0 | 0 | J | | |
|---|----|---|---|---|--|--|
| | | | | | | |
| | | | | | | |
| |)— | | | | | |
| | | | | | | |
| | | | | | | |
| | | | | | | |
| | | | | | | |
| | | | | | | |
| | | | | | | |
| | | | | | | |
| | | | | | | |
| | | | | | | |
| | | | | | | |
| | | | | | | |

Pin

| 1 | –12 V (A)/85 mA |
|---|-----------------------|
| 2 | 0 V (A) |
| 3 | 0 V (A) |
| 4 | +12 V (A)/85 mA |
| 5 | Shield |
| 6 | 0 V (B) |
| 7 | 0 V (B) |
| 8 | Sensor (B) max. ±10 V |
| 9 | +5 V (B)/400 mA |

Assignment

| Pin | Assignment |
|---------|-----------------|
| 1 | TX+ |
| 2 | TX- |
| 3 | REC+ |
| 4 | Do not assign |
| 5 | Do not assign |
| 6 | REC- |
| 7 | Do not assign |
| 8 | Do not assign |
| Housing | External shield |

Switching inputs/outputs on the ND 287

Twelve s

inputs

Six swite

outputs

Switching inputs

The ND 287 evaluation unit features numerous inputs for external operation and outputs for switching functions. The inputs can be addressed with a pulse or a closed contact.

Exception: the switching inputs for transmitting measured values over the data interface are separate for contact and pulse.

The switching input E is active when a LOW signal U_L is applied (contact or pulse to 0 V).

Signal level

 $-0.5 \text{ V} \leq U_L \leq 0.9 \text{ V}$ with $I_L \leq 6 \text{ mA}$ $3.9V \le U_{H} \le 15.0V$ t_{min} ≥ 30 ms

Zero reset / set value

Via an external signal, each axis can be set to the display value zero or to a value stored in a parameter (SET).

External control of measurement series Switching the display to MIN, MAX, and DIFF

Continuously applying a LOW signal at the corresponding switching input activates the external operation of measurement series. The start of a new measurement series and the switch to the MIN/MAX/DIFF display are then externally controlled through further switching inputs.

Ignoring reference mark signals

(reference pulse lock) When this input is active, the readout ignores all of the reference mark signals. A typical application for this is when linear measurement is performed with a rotary encoder and a lead screw.

Activating or deactivating REF mode

After switch-on or a power interruption, the digital readout can be externally switched to REF mode. The next signal then deactivates REF mode (switching function).

Display with axis coupling

The ND 287 can have two optional encoder inputs. Using switching inputs, you can switch the display to individual measured values, a sum, a difference, or any logical operation.

| | ND 287 | |
|-----------|---|---|
| switching | Zero reset, clear error message Set a preset Ext. control of measurement series Start measurement series Display minimum MIN Display maximum MAX Display difference DIFF Measured value output (pulse) Measured value output (contact) Ignore reference mark signals (input Ignore reference mark signals (input Activate or deactivate REF mode | or display f (X1, X2) ¹⁾ or display X2 ¹⁾ or display X1 + X2 ¹⁾ or display X1 - X2 ¹⁾ X1) |
| ching | Display value is "0" Measured value ≥ Switching limit A1 Measured value ≤ Switching limit A2 Measured value > Unper sorting lim | 2 |

Measured value > Upper sorting limit Measured value < Lower sorting limit Error

¹⁾ Also selectable by parameter

E O-


0V O-

F O

0V O-

Contact

Pulse



EIB 700 and IK 220 signal converters

Switching outputs

The ND 287 features open-collector outputs that switch to 0 V (= Active LOW).

Delay until signal output: t_V ≤ 20 ms

Signal level

 $U_L \leq 0.4 \, V$ at $~I_L \, \leq 100 \; mA$ $U_H \le 32 V$ at $I_H \le 10 \ \mu A$

Trigger points (in actual value mode) When the measured value reaches trigger points defined via parameters, the corresponding output becomes active. Up to two trigger points can be defined.

Switch-off ranges (distance-to-go mode) In distance-to-go mode, the trigger points function as switch-off ranges, appearing equidistantly from the display value "0".

Sorting limits


When the tolerance sorting limits as defined via parameters are exceeded, the corresponding outputs become active.


Triggering signal for an error


The ND 200 readouts constantly monitor the measuring signals, input frequency, data output, etc., displaying error messages as they arise. If errors occur that have a significant effect on a measurement or data output, the readout sets a switching output to active. This enables monitoring for automated processes.


Zero crossover


At the display value "0", the corresponding output becomes active. The minimum signal duration is 180 ms.











The EIB 700 and IK 220 units feature D-sub connectors for external operation and the connection of encoders.


With the IK 220, the encoder signals can be routed out over an additional slot cover and are available as 11 µA current signals for further processing in evaluation electronics or EXE pulse-shaping electronics. An additional slot cover holds the connections for the external inputs/outputs (e.g., for storing the measured values).


| | EIB 700 | IK 220 | | | | | |
|---|---|------------------------|--|--|--|--|--|
| Encoder inputs | | | | | | | |
| 1 V _{PP} | 4 ¹⁾ | 2 ¹⁾ | | | | | |
| 11 μA _{PP} | 4 ¹⁾ | 2 ¹⁾ | | | | | |
| EnDat 2.1 | 4 ¹⁾ | 2 ¹⁾ | | | | | |
| EnDat 2.2 | 4 ¹⁾ | - | | | | | |
| SSI | - | 2 ¹⁾ | | | | | |
| Encoder outputs | | | | | | | |
| 11 μΑρρ | - | 2 (optional assembly) | | | | | |
| Trigger input | 4 | 2 (optional assembly) | | | | | |
| Trigger output | 4 | 2 (optional assembly) | | | | | |
| Logic inputs/outputs | 4/4 ²⁾ | 2/- | | | | | |
| ¹⁾ Selectable ²⁾ Can also b | ¹⁾ Selectable ²⁾ Can also be used as a trigger, or as a logic input or output | | | | | | |
| Depends on the inpu | t circuitry of the subsequent electi | ronics Output assembly | | | | | |

External inputs/outputs for the IK 220 Slot cover with two 9-pin D-sub connections (male). ID 340253-01

Accessories

Output assembly for the IK 220 Slot cover with two 9-pin D-sub connections (male), for forwarding the encoder signals (11 μ A_{PP}) to the subsequent electronics. ID 340252-01





| | ١ | • | |
|---|---|---|--|
| 1 | 1 | ١ | |
| | | | |
| | | | |

Encoder inputs

The evaluation electronics are equipped with interfaces for connecting HEIDENHAIN encoders. Other interfaces are available upon request.

Pin layout for $\sim 1 V_{PP}$

| 15-pin D-sub flange socket (female) | | | | | | | | | | | |
|-------------------------------------|---|--------------|----------|---------------|---------------------|----|----|----|----|--------|-----------------|
| | $\begin{array}{c} & & 7 & 6 & 5 & 4 & 3 & 2 & 1 \\ & & & 0 & 0 & 0 & 0 & 0 & 0 \\ & & & 15 & 14 & 13 & 12 & 11 & 10 & 9 \\ & & & & 0 & 0 & 0 & 0 & 0 & 0 \end{array}$ | | | | | | | | | | |
| | 1 | Deuver | ouroph (| | I | | | | | | Othoro |
| | | Power | supply | | Incremental signals | | | | | Others | |
| — | 4 | 12 | 2 | 10 | 1 | 9 | 3 | 11 | 14 | 7 | 5/6/8/ 13/15 |
| \sim 1 V _{PP} | UP | Sensor UP | 0 V | Sensor 0 V | A+ | A– | B+ | В- | R+ | R– | / |

Cable shield connected to housing; U_P = Power supply voltage

Sensor: The sense line is connected in the encoder with the corresponding power line.

Vacant pins or wires must not be used.


Pin layout for □□ TTL

| 9-pin D-sub flange socket (female) | | | | | | | | | |
|------------------------------------|-------|--------|-----------------|----------------------------|--|-----------------|-----------------|-----------------|--------|
| | | |)— | | $ \begin{pmatrix} 5 & 4 & 3 & 2 & 1 \\ \circ & \circ & \circ & \circ & \circ \\ 9 & 8 & 7 & 6 \\ \circ & \circ & \circ & \circ \end{pmatrix} $ | | | | |
| | Power | supply | | Incremental signals Others | | | | | Others |
| \sim | 7 | 6 | 2 | 2 3 4 5 9 8 | | | | | 1 |
| плш | UP | 0 V | U _{a1} | U _{a1} | U _{a2} | U _{a2} | U _{a0} | U _{a0} | / |

Cable shield connected to housing; U_P = Power supply voltage

Vacant pins or wires must not be used!

Pin layout of the ND 200 and GAGE-CHEK series with \sim 1 V_{PP}/ \sim 11 μ A_{PP}/EnDat



Shield on housing; **U**_P = Power supply voltage

Sensor: The sense line is connected in the encoder with the corresponding power line. Vacant pins or wires must not be used!

Pin layout of the EIB 700 series with $\sim 1 V_{PP}$

| 15-pin D-sub | flange s | socket (fen | nale) | | | | | | | | | | | |
|--------------------------|----------|--------------|--------|--------------|--------------------|-----------------|-------------------|--|-------------------------------|-----------------|-----------------|---------------------------|---------------------------|---------|
| | | | |) | - | | 8 0 1! 0 | 7 6 5 4 3 0 0 0 0 0 5 14 13 12 11 0 0 0 0 0 | 3 2 1 0 0 0 10 9 0 0 | | | | | |
| | | Power | supply | | | | In | cremen | ntal signa | als | | | Others | |
| \sim | 4 | 12 | 2 | 10 | 6 | 1 | 9 | 3 | 11 | 14 | 7 | 8 | 6 | 5/13/15 |
| \sim 1 V _{PP} | UP | Sensor UP | 0 V | Sensor 0V | / | A+ | A- | B+ | B- | R+ | R- | L1/H ¹⁾ | L2/L ¹⁾ | / |
| \sim 11 µApp | • | | • | - | Internal shield | I ₁₊ | I ₁₋ | I ₂₊ | I ₂₋ | I ₀₊ | I ₀₋ | / | / | / |

Shield on housing; **U**_P = Power supply voltage

Sensor: The sense line is connected in the encoder with the corresponding power line. Vacant pins or wires must not be used!

¹⁾ Pins for homing or limit signals if supported by the encoder

 $\left[\begin{smallmatrix} 8 & 7 & 6 & 5 & 4 & 3 & 2 & 1 \\ 0 & 0 & 0 & 0 & 0 & 0 & 0 \\ 15 & 14 & 13 & 12 & 11 & 10 & 9 \\ 0 & 0 & 0 & 0 & 0 & 0 & 0 \\ \end{smallmatrix}\right]$

| _ | | | | | | | | | | | |
|---|-----------------|-----------------|-----------------|-----------------|----------------------|------|-------|-------|--|--|--|
| ſ | cremen | tal signa | ls | | Serial data transfer | | | | | | |
| | 3 | 11 | 14 | 7 | 5 | 13 | 8 | 15 | | | |
| | B+ | В- | R+ | R– | / | / | / | / | | | |
| | I ₂₊ | I ₂₋ | I ₀₊ | I ₀₋ | / | / | / | / | | | |
| | / | / | / | / | DATA | DATA | CLOCK | CLOCK | | | |

EIB application software for the EIB 700

En Device overniew En ElB 1 Axis 1 Axis 2 Axis 3 Axis 4 Auditary axis

The EIBs had been successfully initialized.

Pin layout of the EIB 700 series with EnDat

| 15-pin D-sub | flange | socket (fe | male) | > | | | (| 8 7 6 5 4 0 0 0 0 0 15 14 13 12 1 0 0 0 0 0 | 3 2 1 0 0 0 1 10 9 0 0 0 0 0 0 | | | | | |
|--------------|----------------|--------------|----------|---------------|--------------------|----|---------|--|--------------------------------|------|------------|------------|-------|--------|
| | | Power | supply | | | In | crement | al signals | 1) | | Serial dat | ta transfe | r | Others |
| Ţ | 4 | 12 | 2 | 10 | 6 | 1 | 9 | 3 | 11 | 5 | 13 | 8 | 15 | 7/14 |
| EnDat | U _P | Sensor UP | 0 V • | Sensor 0 V | Internal shield | A+ | A- | B+ | В- | DATA | DATA | CLOCK | CLOCK | / |

Shield on housing; U_P = Power supply voltage

Sensor: The sense line is connected in the encoder with the corresponding power line.

Vacant pins or wires must not be used!

¹⁾ For encoders with ordering designations EnDat01 and EnDat02

Pin layout of the IK 220

| 15-pin D-sul | o flange | socket (n | nale) | | | | | | | | | | | | |
|---------------------|----------|--------------|----------------------|--------|--------------------|-----------------|-----------------|-----------------|----------------------------|-----------------|-----------------|------|------------|-----------|-------|
| | | | | - | - | | | | 3 4 5 6 7 11 12 13 14 1 | 8 5 | | | | | |
| | | Power | supply | | | | In | cremen | ital signa | als | | | Serial dat | a transfe | r |
| | 1 | 9 | 2 | 11 | 13 | 3 | 4 | 6 | 7 | 10 | 12 | 5 | 8 | 14 | 15 |
| 11 μΑ _{ΡΡ} | Up 5V | Sensor 5V | U _N 0V | Sensor | Internal shield | I ₁₊ | I ₁₋ | I ₂₊ | I ₂₋ | I ₀₊ | I ₀₋ | / | 1 | 1 | / |
| 1 V _{PP} | ⊷ | • | • | • | | A+ | A– | B+ | B- | R+ | R– | / | / | 1 | / |
| EnDat SSI |] | | | | | A+ | A- | B+ | В- | / | / | DATA | DATA | CLOCK | CLOCK |

Shield on connector housing

Vacant pins or wires must not be used.

The EIB application software covers two applications:

Configuring and demonstrating the EIB 700

- Easy configuration of settings required for operating the EIB 700 (e.g., input interface, data packets, operating mode, trigger settings)
- Management of one or more EIB 700 units
- Simple depiction of the positions transmitted by the EIB 700
- Saving of settings for management of different application projects For more information, please refer to the User's Guide.

Platform for customized applications

The EIB application software is provided as source code, thereby allowing customers to rapidly implement their own applications. The application software was programmed using C++/CLI and Windows Forms in Visual Studio 2008. This programming environment is widely used in technical application programming but does not necessarily provide state-of-the-art user interfaces such as those in Windows 10. However, adaptation to other graphical interfaces can be performed by the customer.



Summary display

| mary display Display options Status REF TRIG 32,437 32,437 vis 1 Start REF Clear Avis 2 Status REF TRIG Status Status REF TRIG Status Status REF TRIG Status Status REF TRIG Status 33,617 mm vis 3 Stat REF Clear Avis 4 Start REF Clear | | | sition | | | | EIDENHA |
|--|-------------|--------------|----------|--------|-----------|---------|---------|
| 32,437 10,732 is 1 Start REF Clear Status REF TRIG 33,617 mm 2038: 306,991 | nary displa | y Display of | ptions | | | | |
| Avis 2 Start REF Clear Avis 2 Start REF Clear Status REF TRIS 33,617 mm 2038 : 306,991 | Status | REF | TRIG | Status | REF | TRIG | |
| Status REF TRIG Status REF TRIG 33,617 mm 2038 : 306,991 * 2038 : 306,991 * 306,991 * | | | 32,437 . | | | 10,732 | |
| 33,617 mm 2038 : 306,991 · | dis 1 [| Start REF | Clear | Axis 2 | Start REF | Clear | |
| | Status | REF | TRIG | Status | REF | TRIG | |
| vis 3 Start REF Clear Avis 4 Start REF Clear | | | 33,617 m | m | 2038 : | 306,991 | • |
| | dis 3 | Start REF | Clear | Axis 4 | Start REF | Clear | |
| | | | | | | | |
| | Falland | | | | | | |
| informed in the second se | ly started. | | | | | | |
| laized. y started. | | | | | | | |
| | | | | | | | |
| | | | | | | | |

HEIDENHAIN

DR. JOHANNES HEIDENHAIN GmbH

www.heidenhain.de

Vollständige und weitere Adressen siehe www.heidenhain.de For complete and further addresses see www.heidenhain.de

| DE | HEIDENHAIN Vertrieb Deutschland 83301 Traunreut, Deutschland © 08669 31-3132 Ext 08669 32-3132 E-Mail: hd@heidenhain.de |
|----|---|
| | HEIDENHAINTechnisches Büro Nord 12681 Berlin, Deutschland |
| | HEIDENHAIN Technisches Büro Mitte 07751 Jena, Deutschland |
| | HEIDENHAIN Technisches Büro West 44379 Dortmund, Deutschland © 0231 618083-0 |
| | HEIDENHAIN Technisches Büro Südwest 70771 Leinfelden-Echterdingen, Deutschland © 0711 993395-0 |
| | HEIDENHAIN Technisches Büro Südost 83301 Traunreut, Deutschland 08669 31-1337 |
| AR | NAKASE SRL. B1653AOX Villa Ballester, Argentina www.heidenhain.com.ar |
| AT | HEIDENHAIN Techn. Büro Österreich 83301 Traunreut, Germany www.heidenhain.de |
| AU | FCR MOTION TECHNOLOGY PTY LTD Laverton North Victoria 3026, Australia E-mail: sales@fcrmotion.com |
| BE | HEIDENHAIN NV 1760 Roosdaal, Belgium www.heidenhain.be |
| BG | ESD Bulgaria Ltd. Sofia 1172, Bulgaria www.esd.bg |
| BR | HEIDENHAIN Brasil Ltda. 04763-070 – São Paulo – SP, Brazil www.heidenhain.com.br |
| BY | GERTNER Service 220026 Minsk, Belarus www.heidenhain.by |
| CA | HEIDENHAIN CORPORATION Mississauga, OntarioL5T2N2, Canada www.heidenhain.com |
| СН | HEIDENHAIN (SCHWEIZ) AG 8603 Schwerzenbach, Switzerland www.heidenhain.ch |
| CN | DR. JOHANNES HEIDENHAIN (CHINA) Co., Ltd. Beijing 101312, China www.heidenhain.com.cn |

CZ HEIDENHAIN s.r.o. 102 00 Praha 10, Czech Republic www.heidenhain.cz

- Denmark → SE DK ES FARRESA ELECTRONICA S.A. 08028 Barcelona, Spain www.farresa.es FI **HEIDENHAIN Scandinavia AB** 01740 Vantaa, Finland www.heidenhain.fi **HEIDENHAIN FRANCE sarl** FR 92310 Sèvres, France www.heidenhain.fr HEIDENHAIN (G.B.) Limited Burgess Hill RH15 9RD, United Kingdom GB www.heidenhain.co.uk GR **MB** Milionis Vassilis 17341 Athens, Greece www.heidenhain.gr HR Croatia \rightarrow **SL** HU HEIDENHAIN Kereskedelmi Képviselet 1239 Budapest, Hungary www.heidenhain.hu **PT Servitama Era Toolsindo** Jakarta 13930, Indonesia ID E-mail: ptset@group.gts.co.id NEUMO VARGUS MARKETING LTD. IL Holon, 5885948, Israel E-mail: neumo@neumo-vargus.co.il IN **HEIDENHAIN Optics & Electronics India Private Limited** Chetpet, Chennai 600 031, India www.heidenhain.in
- IT HEIDENHAIN ITALIANA S.r.I. 20128 Milano, Italy www.heidenhain.it
- JP HEIDENHAIN K.K. Tokyo 102-0083, Japan www.heidenhain.co.jp
- KR HEIDENHAIN Korea Ltd. Anyang-si, Gyeonggi-do, 14087 South Korea www.heidenhain.co.kr
- MX HEIDENHAIN CORPORATION MEXICO 20290 Aguascalientes, AGS., Mexico E-mail: info@heidenhain.com
- MY ISOSERVE SDN. BHD. 43200 Balakong, Selangor E-mail: sales@isoserve.com.my
- NL HEIDENHAIN NEDERLAND B.V. 6716 BM Ede, Netherlands www.heidenhain.nl
- NO HEIDENHAIN Scandinavia AB 7300 Orkanger, Norway www.heidenhain.no

| irthe | Adressen siehe www.heidenhain.de r addresses see www.heidenhain.de |
|-------|--|
| NZ | Llama ENGINEERING Ltd 5012 Wellington, New Zealand E-mail: info@llamaengineering.co.nz |
| PH | MACHINEBANKS' CORPORATION Quezon City, Philippines 1113 E-mail: info@machinebanks.com |
| PL | APS 02-384 Warszawa, Poland www.heidenhain.pl |
| РТ | FARRESA ELECTRÓNICA, LDA. 4470 - 177 Maia, Portugal www.farresa.pt |
| RO | HEIDENHAIN Reprezentanță Romania Brașov, 500407, Romania www.heidenhain.ro |
| RS | Serbia → BG |
| RU | GERTNER Service 119002 Moscow, Russian Federation www.heidenhain.ru |
| SE | HEIDENHAIN Scandinavia AB 12739 Skärholmen, Sweden www.heidenhain.se |
| SG | HEIDENHAIN PACIFIC PTE LTD Singapore 408593 www.heidenhain.com.sg |
| SK | KOPRETINATN s.r.o. 91101 Trencin, Slovakia www.kopretina.sk |
| SL | NAVO d.o.o. 2000 Maribor, Slovenia www.heidenhain.si |
| тн | HEIDENHAIN (THAILAND) LTD Bangkok 10250, Thailand www.heidenhain.co.th |
| TR | T&M Mühendislik San. veTic. LTD. ŞTİ. 34775 Y. Dudullu – Ümraniye-Istanbul, Turkey www.heidenhain.com.tr |
| TW | HEIDENHAIN CO., LTD. Taichung 40768, Taiwan www.heidenhain.com.tw |
| UA | GERTNER Service 02094 Kiev, Ukraine www.heidenhain.ua |
| US | HEIDENHAIN CORPORATION Schaumburg, IL 60173-5337, USA www.heidenhain.us |
| VN | AMS Co. Ltd HCM City, Vietnam |

ZA MAFEMA SALES SERVICES C.C. Kyalami 1684, South Africa www.heidenhain.co.za

E-mail: davidgoh@amsvn.com